

Cable Dog Reaving Manual

When the low profile cable dog (1-3/8" high) is used, the cable needs to go around the knife slot, as opposed to straight through the dog. Pulling the cable through the angled pathway is a bit tricky, but the following instructions will help.

Step 1. Peel out and cut each core of the cable, cutting each succeeding core 1" farther down the cable from the previous cut:



When finished, the tapered cable should look like this:



Step 2. Wrap electrical tape around the tapered end, starting at the end and working down past the last cut. Be careful to fold the cut ends back into the cable when taping. When finished, the cable should look like this:



Step 3. Now the cable can be guided through the cable slot in the dog. One final suggestion is to run something (fish-tape, tie-wrap, coat hanger, etc...) through the slot from the other direction, tape it to the tapered cable and pull it back through.